

# STICK4

## 4INCH TOOTHPICK FPV DRONE


### INSTRUCTIONS



Brand Name	AURORA RC	Drone Name	STICK4
Flight Controller	F411 AIO 30A Upgrade firmware version:MATEKF411	ESC	BLHELI S 30A (built-in)
Motor	T-MOTOR F1507 2700KV	Propeller	Gemfan Flash 4032-3
Camera	CADDX.US Turbo EOS2	VTX	25-50-100-200-400mW 40CH

1

Power control: Press and hold the key for 6 seconds and the R light flash, then press the key to change the power level 25mw/50nW/100mw/200mW/400mW.




RF POWER LED	25mW	50mW	100mW	200mW	400mW	Fault
R	1time	2times	3times	4times	5times	●
Frequency Table(Mhz)						
CH C5 C2 C1	○○○	○○○	○○○	○○○	○○○	○○○
FR(C4)	CH1	CH2	CH3	CH4	CH5	CH6
A 1 time	5865	5845	5825	5805	5785	5765
b 2 times	5733	5752	5771	5790	5809	5828
E 3 times	5705	5685	5665	5645	5625	5605
F 4 times	5740	5760	5780	5800	5820	5840
f 5 times	5658	5695	5732	5769	5806	5843
	○ off	● on	● Flash			

The frequency marked in orange can only be used after obtaining the ham license certificate.

3

### FLIGHT CONTROLLER F411 AIO 30A



### FREQUENCY AND OUTPUT POWER CONTROL

Frequency and power control methods with BF OSD, you can change it with your transmitter.

Key frequency control: Press the key to change the CH1-8.

Press and hold the key for 3 seconds and the C4 light flash, then press the key to change the frequency group FR(A-R).

2

### CONNECT TO THE TRANSMITTER

#### BNF-Frsky D16 mode

1, Turn on the transmitter while holding the F/S button on the module (please refer to the module instruction manual for switch positions).

Release the button. The RED LED on the Module will flash, indicating the transmitter is ready to bind to the receiver.

2, Connect battery to the XM+receiver while holding the F/S button on the receiver. The LED on the receiver will flash, indicating the binding process is completed.

3, Turn off both the transmitter and the receiver.

4, Turn on the transmitter and connect the battery. The GREEN LED on the receiver indicates the receiver is receiving commands from the transmitter.

The receiver/transmitter module binding will not have to be repeated, unless one of the two is replaced.

#### BNF-Flysky AFHDS 2A

1, Press and hold the receiver BIND key then plug in battery, when the light flashes, the receiver enters the code state, release the BIND key;

2, Use the transmitter to enter the code mode;

3, when the receiver's light flashes from fast to slow means the success of the code;

4, Restart the transmitter, reenergized the drone, when the receiver's light is on, the connection is done;

5, The light is on when working.

4