Language modification:

1. After starting up, click the video button. When the screen displays, click the menu button.

2. Press the key to select the last option on the screen(工具--Settings), click

the button to confirm, and enter the Settings.

3. Click the to select the 语言 option, click the button to confirm,

you can see that English is available, select English.
4. Finally, click the Back button to return to the main menu.