

Instructions

Thermo-hygrometer Alarm Clock with timer

Getting Started

Remove the plastic tab from the back to

activate the battery and turn on it

TIME SET (time mode)

1.Press the "MODE">3 seconds,Enter clock

setting, Hour flash

2.press "+/MIN" and "SEC/-" adjust the fit numerical value

3. Short press "MODE", Min. flash

4.press "+/MIN" and "SEC/-" adjust the

fit numerical value,finish the time

At time mode press "MIN/+ " to

setting 12hr. or 24hr.,press "SEC/-"

to settin C or F



①

ALARM SET

At time mode short press the "MODE"

change time mode to alarm mode,second

point no flash,

1.Press the "MODE">3 seconds,Enter Alarm setting, hour flash

2.Press "+/MIN" and "SEC/-" adjust the fit numerical value,

3.Short press "MODE" finish hour setting and enter min.

setting,min. flash,

4.Press "MIN/+ " and "SEC/-" adjust the fit numerical value.

5.Press "MODE" finish setting and auto open Alarm icon.

At alarm mode, short press the "MIN/+ " to turn on or turn off alarm.

when alarm sound press "MODE" enter 5min. snooze, press other

buttons to stop alarm.



②

TIMER SET

At time mode press "MODE" twice, enter Timer mode,

Counting Down

1.Press "+/MIN" and "SEC/-" to set a countdown time.

2.Press "Start/Stop" to begin counting down.

When the timer reaches zero,an alarm will sound,press any

button to silence the alarm.

At Counting Down mode, Press the "+/MIN" and "SEC/-" buttons

simultaneously to set the timer to zero.

Counting Up

1.Press the "+/MIN" and "SEC/-" buttons simultaneously

to set the timer to zero.

2.Press "Start/stop" to begin counting up,and press it again to stop

the timer.



③

TEMPERATURE

measuring range:-9.9 °C ~ +70 °C ,resolution ratio:0.1 °C ,out

ranges: LL.L or HH.H

HUMIDITY

measuring range: 20% ~ 99%,resolution ratio:1%,out ranges: LL.L

or HH.H Environmental Comfort : DRY ☞, WET ☞, COMF ☞

Battery: CR2032 1PC.

REMARK

1.For tabletop display,pull out the stand and set on table or other flat surface.to display on a magnetic surface push in the stand so it clicks into place.Then stick it to the magnetic surface

2. Remove the screw on the battery compartment using a small Phillips screwdriver. Slide off the battery door,remove the old battery(CR2032), and insert a new one.then reassemble the battery compartment,remembering to replace the screw.

④

使用說明書

產品名稱:大螢幕鬧鐘計時器溫濕度計

開機通電，拉出電池門處電池絕緣片上電全顯示
時間設置

- 1.時鐘模式按住[MODE]鍵3秒，小時閃動，
- 2.短按[+ /MIN]鍵或[SEC/-] 鍵調整所需小時值，長按快速調整
- 3.短按[MODE]鍵分鐘閃動，按[+ /MIN]鍵或[SEC/-] 鍵調整所需分鐘值，
- 4.短按[MODE]鍵確認設置(如沒有任何操作30秒後自動確認並退出設置)



①

鬧鐘設置

時鐘顯示模式下,短按[MODE]鍵一次轉換到鬧鐘模式，
濕度位置顯示AL標識,秒點不閃，

- 1.長按[MODE]鍵3秒以上，小時閃動，響鬧鈴鐺符號 自動顯示出來.

短按[+ /MIN]鍵或[SEC/-]鍵調整所需小時值，長按快速調整

- 2.短按[MODE]鍵,分鐘閃動，按[+ /MIN]鍵或[SEC/-]鍵調整所需分鐘值，

- 3.按[MODE]鍵確認並完成設置，
在鬧鐘模式按[MODE]鍵關閉或打開鬧鈴並出現鈴鐺符號

當鬧鈴聲響起時，按一下[+ /MIN]鍵進入5分鐘貪睡，
按其他按鍵停止響鬧。直到第二天同樣時間開啟響鬧



②

正計時

時鐘模式下，短按二次[MODE]鍵，轉到計時器模式，顯示
M S 標識字母

顯示 00:00

1. 短按[START/STOP]鍵開始正計時，
2. 正計時進行時，短按[START/STOP]鍵暫停正計時
並顯示當前正計時的時間值，再按又開始正計時，
達到最大正計時99分59秒，
3. 在正計時狀態下,同時按下 [+ /MIN]鍵或[SEC/-]鍵
會清零顯示00:00,



③

倒計時。

時鐘模式下，短按二次[MODE]，轉到計時器模式，顯示 M S 標
識字母。

顯示00:00。

1. 短按 [+ /MIN]鍵或[SEC/-]鍵調整所需的分鐘和秒數，
長按快速調整。
2. 按[START/STOP]鍵開始倒計時，當倒計時到00:00時,會有
最長1分鐘響聲提示；
3. 倒計時進行時，短按[START/STOP]鍵暫停倒計時。
並顯示當前倒計時的時間值，再按又開始倒計時。
4. 在倒計時狀態下,同時按下 [+ /MIN]鍵或[SEC/-]。
會清零顯示00:00。

溫度功能

溫度測量範圍:-9.9 °C ~ +70 °C,溫度解釋度:0.1 °C,超出範圍顯示:

LLL 或 HH.H。

濕度功能

濕度測試範圍: 20% ~ 99%,濕度解釋度:1%,超出範圍顯示: LLL

或 HH.H。

環境舒適度分為: 乾燥 ☀,舒適 ☁,和潮濕 ☔。

使用電池: 一枚CR2032。

備註:

1. 拉出背後支架，可以放地檯面使用，機內有磁石，收回支架，
可以貼在鐵質的平面。
- 2.打開背後的電池蓋的十字螺絲，移出電池蓋，可以更換一枚新的
CR2032電池。

④