

指纹锁 FINGERPRINT LOCK











I .USB Interface:

The product is charged by USB. Please fully charge the product for the first time.



Components:

1.USB Port 3.LED Light

2.Fingerprint Reader 4.Lock Beam

II .Indicator

Use 3-color indicator. Different indicator represents different devices and status.

Please check the details as below chart:

Indicator status	Function
Low power	Red light flash
Charging	Red light always on
Full charged	Lights off
Green light flash	Fingerprint collection mode
Green light always on	Successful to collect fingerprint
Blue light always on	Administrator fingerprint authorization
Green light flash	Unlocked successfully
Red light always on	Delete fingerprint mode
Red light flash	Failed to collect fingerprint

III . Description Of First Administrator's Fingerprint Record



1.Long press sensor 3

2.Left your finger when blue light flash

3.Start record the fingerprint when green light flash


4.Record 10 times with the same finger, and the blue light and green light flashes



6. I of all of 10 times of collector was successful, with a loud sound "Di", and green light flash continuously, the administrator's fingerprint was recorded successfully.

5.It records successful when blue light flash

IV. Number 2 to 10 Fingerprint Recording Instructions



- 5.lt records successful when blue light flash
- retriens.

 1. The first and second fingerprints are the administrator fingerprint by default.

 2. Collecting the second to tenth fingerprints requires administrator fingerprint authorization.

V.Description Of Delete Fingerprint





authorize fingerprint when red light flash continuously



3.The fingerprint deleted successfully when green light flash continuously and sound continuously

VI.Specifications

Support 360 degree angel fingerprint recognize Resolution: 508DPI ESD: +/-12kV air, +/-8kV contact FRR: <1% FAR: <0.002% Recognize time: <300mS Battery: 3.7V 300mAh Charger: 5V 1A

Remarks:
Only the administrator can delete the fingerprint and delete all the fingerprints at once.

VII.Low voltage

When the voltage ≤3.5V, the red indicator flash fast for 15s. If keep in the status of low batter, it will alarming per minute.

-、USB接口:

设备通过数据线连接USB进行充电。 (首次使用请先给设备充满电。)



部件识别: 1 USB接口

3.LED指示灯

2.指纹采集器 4.锁梁

二、指示灯

采用3色指示灯,指示灯不同颜色,不同状态代表设备不同

状态。详情见卜表:	
状态	指示灯状态
电量低	红灯闪烁
充电中	红灯长亮
充满电	灯灭
绿灯闪烁	指纹采集模式
绿灯长亮	指纹采集成功
蓝灯长亮	管理员指纹授权
绿灯闪烁	解锁成功
红灯长亮	清除所有指纹模式
红灯闪烁	指纹采集失败

三、首次(管理员)指纹录入说明



四、第二个到第十个指纹录入说明



六、规格参数

五、删除指纹说明







管理员指纹授权。



分辨率508DPI;

支持360°任意方向按压式指纹识别;

分辨率508DPI: ESD: +/-12k/空气, +/-8k/接触; FRR: <1%; FAR: <0.002%; 识别时间: <300mS; 电池容量: 3.7V 300mAh 东电电压: 5V 1A

备注:

只有管理员才能删除指纹,并且是一次性删除全部指纹。

七、低压

当电压等于或低于 3.5V 时红色指示灯会快闪 15 秒;如一直处于低电状态,每隔一分钟,就报警一次。