


中文简体

# 无线麦克风 使用说明书 型号: K380H

## 一. 产品简介



- 1.电源键
- 2.SET键 (短按改变工作频道, 有十个频道可选)
- 3.电池状态
- 4.无线信号强度
- 5.工作频道 (CH01-CH10)

- 6.低电指示灯(橙色)
- 7.话筒接收指示灯 (蓝色)
- 8.蓝牙状态灯 (蓝色)
- 9.充电指示灯 (红色)
- 10.PWR:电源开关
- 11.PAIR:蓝牙配对按钮
- 12.DC5V: 充电口

## 二. 技术参数

工作频段: UHF  
 可变频道: 10个  
 失真度: ≤0.5%  
 使用距离 > 10M  
 拾音器: 动圈式咪芯  
 供电方式: 接收器内置可充电锂电池

## 三. 配件清单

|              |    |
|--------------|----|
| 手麦           | 1个 |
| 接收器          | 1个 |
| USB充电线       | 1条 |
| D3.5转D6.5转接头 | 1个 |
| D3.5转接线      | 1条 |
| 防滑圈          | 1个 |

## 四.使用方法说明

### 1.麦克风使用方法

旋转打开尾管, 安装两节五号电池, 短按电源键开机 (长按关机); 开机状态, 短按SET键可改变手麦的工作频道, 共有十个频道可以选择, 从CH01-CH10。

### 2.接收器使用方法


**蓝牙连接:** 按PAIR键蓝牙指示灯闪烁, 确保接收器蓝牙在配对状态下, 在手机等设备点开设置-蓝牙-搜索设备中找到K380H, 并点选K380H完成连接, 播放手机上的音乐就可以将伴奏音传到音响上了。

### 3.充电, 低电指示说明

**充电:** 充电时接收器指示灯红灯亮, 充满时红灯灭。

**低电:** 当电量过低时, 手麦显示屏有电亮显示; 接收器指示灯橙灯闪烁, 直至自动关机。

## 五.产品连接示意图



## 六.简易故障处理


### 1.手麦或接收器不开机:

手麦电池电量不足, 请更换电池; 若接收器无电, 请用USB线给接收器充电。

### 2.麦克风的声嘶叫:

麦克风的咪头与音响靠太近, 或音响音量过大, 适当降低音响音量或远离音响。

## I. Product introduction



- |   |  |
|---|--|
| 1. Power key  | 7. Microphone receiver LED indicator(blue) |
| 2.SET key : short press to change working channel, 10 channels optional | 8. Bluetooth status indicator (blue)       |
| 3. Battery status   | 9. Charging indicator(red)                 |
| 4.Wireless signal intensity   | 10.PWR: PWR: power switch                  |
| 5.Working channel CH01-CH10)  | 11.PAIR: PAIR: Bluetooth pair button       |
| 6. low-battery indicator (orange)                                       | 12.DC5V: charging port                     |

## II. Technical parameters

Working frequency band: UHF

Variable channels: 10

Distortion factor:  $\leq 0.5\%$

Operating range > 10m

Vibration pickup: moving coil type microphone core

Power supply: built-in rechargeable lithium battery

## III.Packaging List

|                        |   |
|------------------------|---|
| Microphone             | 1 |
| Receiver               | 1 |
| USB charging line      | 1 |
| D3.5 to D6.5 connector | 1 |
| D3.5 Connecting line   | 1 |
| Anti-skid ring         | 1 |

## IV. Instructions

### 1. Microphone usage

Turn on the tailpipe, install two No.5 batteries, short press the power button to turn on (long press to shut down);


### 2.Receiver usage

Bluetooth connection: Press PAIR button and bluetooth indicator flashes to ensure the receiver bluetooth is in "pairing" mode; Click settings-bluetooth-search in mobile phone to find and click K380R for connection; Play the music on mobile phone, thus background music is uploaded to stereo.

### 3.Charging, low power indication

Charging: Receiver' s red LED indicator is on when charging, and red light goes off when fully charged; Low-power: Low battery indicator of speaker microphone shows when the power is low; Receiver' s orange LED indicator flashes, with warning tone.

## V. Product connection diagram



## VI. Simple fault treatment

1. Speaker microphone or receiver fails be turned on: Please replace the battery when it indicates low battery power; If the receiver is not powered, use USB cable to charge.

2.Sound of microphone:

When microphone is too close to the stereo or sound volume is too high, reduce the sound volume or keep away from the stereo.