


1. Remove the battery compartment cover and install 2 AAA batteries (NOT INCLUDED). A green indicator light on the remote control will turn on.




2. Press the on/off button slightly at the abdomen of Go Go Bird, the green light indicates that Go Go Bird is on.



QUICK START GUIDE

3. Press the top trigger button on remote control to make the wings begin to flap. Gently toss Go Go Bird forward to let it start flying.



4. Use the joystick to steer Go Go Bird and use the buttons to command it to fly in specific patterns. Press the trigger button to make Go Go Bird start and stop flapping its wings.

