

Identifier
Configuration/MSP
Serial Rx

USB VCP
115200 ▼

UART1
115200 ▼

When use SBUS/IBUS/DSM receiver, turn on Ports **UART1** as serial RX