

遥控手表说明书

R/C WATCH MANUAL




1: 开机
开机长按25开关机，开关机的
时候3个LED同时的快速闪烁3下

2: 开机后

- A: 在没有对上码和归零前3个LED慢闪
- B: 对上码和归零后最左边的LED常亮
- C: 有按键动作，3个LED做跑马灯闪烁
- D: 暂停操作时最左边的LED快闪
- E: 充电时最右边的LED灯常亮，充满电熄灭。

3: 没有按下指尖按键 (操作功能)



手表往前—车子前进
手表往后—车子后退
手表往左—车子左横
手表往右—车子右横



手表往前左—车子左斜前
手表往前右—车子右斜前
手表往左后—车子左斜后
手表往右后—车子右斜后

手表上下摆动—车子遥控变形
(备注：根据产品配置不同，此操作功能不同，
分别为：灯光控制/升降调节/扭变变形)

4: 按下指尖按键 (操作功能)



按下指尖按键



手表往前—自动演示功能
手表往后—车子MP3歌曲



手表往左—车子左旋转
手表往右—车子右旋转



手表前左—车子前进左转
手表前右—车子前进右转
手表左后—车子后退左转
手表右后—车子后退右转



手表上下—暂停/恢复操作



- 1: Press 25 long to turn on or off the machine. The 3 LED will flash quickly simultaneously three times when the machine is turned on or off.
- 2: After the machine is turned on
- A: Before the code is paired and reset is done, the three LED will flash slowly
- B: After the code is paired and reset is done, the leftmost LED will flash constantly
- C: When there is keystroke, the three LED will flash scrolling
- D: The leftmost LED flashes when the operation is paused
- E: When charging the rightmost LED light is always on, and the battery is fully charged.

3: A: Fingertip key is not pressed down (Operational function)



Front of the watch —
the automobile will move on
Back of the watch —
the automobile will retreat
Left of the watch —
the automobile will move to the left laterally
Right of the watch —
the automobile will move to the right laterally



Front and left of the watch —
the automobile will start left and front
Front and right of the watch —
the automobile will start right and front
Back and left of the watch —
the automobile will start left and back
Back and right of the watch —
the automobile will start right and back
Up and down of the watch —
the automobile will become deformed

Watch swings up and down —
car remote control deformation
(Note: This operation is different depending on the product configuration.
They are lighting control / lifting adjustment / torsional deformation)

4: press the fingertip button (Operational function)



Press and hold the
fingertip button



Front of the watch—automatic presentation
Back of the watch —car MP3 song



Left of the watch—car left rotation
Right of the watch —car right rotation



Front and left of the watch — car goes ahead and turns left
Front and right of the watch — car goes ahead and turns right
Back and left of the watch — car goes back and turns left
Back and right of the watch — car goes back and turns right



Up and down of the watch —
pauses/resume operation