
装箱清单

打开产品包装后,请您确认摄像机是否完好,对照下图确认配件是



(ES系列)

快速操作指南









外观介绍

使用前请先熟悉摄像机。





注:为方便安装电池,电池仓盖螺丝出厂未锁死,请用户安装 完电池后自行锁死螺丝,另配两颗螺丝做备用

操作步骤

1.下载安装APP

方法一:扫描二维码快速下载;



超级看看

方法二:在手机应用商店里搜索"超级看看"并下载;

2.开启设备

先安装内存卡,然后安装电池,开启设备(内存卡不支持 热插拔,请在设备断电情况下,插拔内存卡)

3.摄像机网络配置

01.用户登录

- 打开"超级看看"APP讲入登陆界面,如果您有微信可以直接使用 "微信快速登录"(图1);
- 您也可以注册新账号并登录(图1);



02.网络连接

- 进入APP点击右上角"+"进入设备配置页面,点击 "添加我 的设备"。(图2)
- 长按枪机上Reset键6秒使设备恢复出厂默认设置后短按1次 Reset键进入网络配置模式。
- 按APP提示输出需要连接的无线网络账号及密码完成配置。(图3)



注:设备将在开机3分钟后进入休眠状态,请在短按Set按键进入网络 配置模式后的3分钟内进行下一步操作,超时请重新短按Set键

添加成功后,手机通过APP可以对设备进行各种访问,设备 有以下几个状态:



03.访问设备

设备电量不足或者网络故障导致离线;




该状态下设备不支持手机远程唤醒(或者设备被 设置成禁止远程唤醒),如果手机要访问设备,

深度休眠 可以通过手动按下设备的按钮唤醒;



该状态下设备处于低功耗模式,可以通过手机进



该状态下手机可以对设备进行各种访问;

04.消息接收

当人体感应器感应到人体移动时,设备会给手机发送消 息,您可以通过以下两种方式接收消息

1.诵过微信接收消息





2.通过APP接收消息



设备通知消息中 设置接收消息



设备通知消息中 设置微信互联

微信中搜索并关 注 "超级看看" 公众号



O: 摄像机如何恢复出厂默认?

常见问题

A: 方法一: 打开摄像机的设置界面, 在"设置-通用-关于设备"界面, 点击 "恢复出厂设置",即可将摄像机恢复到出厂默认配置(此过程中,请勿 切断摄像机的电源),

方法二:用螺丝刀将摄像机底部的盖板打开,长按Reset键6秒后松开,即可 将摄像机恢复到出厂默认设置。

O: 为何存储视频都为几十秒的短视频?

A: 该设备为人体感应触发型设备,只有在感应到有人体经过时才会 录制一段视频并再次进入休眠。

- 请在使用本产品的同时修改用户密码,以免被不法分子盗用。
- 请勿将设备安装在潮湿、有灰尘、儿童容易接触到的场所
- 请在允许的温湿度范围内使用和贮存,切勿随意拆卸设备。

⚠ 特别声明

- 产品请以实物为准,说明书仅供参考。
- APP和产品设备固件会不定期更新,如有升级请自行在线升级,恕 不另行通知,说明书仅供参考。
- 说明书可能包含技术上不准确的地方或与产品功能不相符的或印刷 错误的地方,请以本公司最终解释为准。

产品保修卡

产品名称

购买日期 经销商 故障处 理情况 性别 邮编


保修期限:一年 本保修卡适用于您购买的本公司系列产品

Packing list

SOLAR POWER CAMERA

Quick Manual

After open packing list box .please check product body and accessories as blow:




Camera×1


(Optional)



Interface

Before use .please pay attention to the interface and button of





Note: in order to facilitate the installation of the battery, the screw of battery cover has not been locked when it left the factory, Please lock the screw by yourself after installing the battery, and use two other screws as backup.

1.Download APP

Operation

Tips one:Scan QR code.



Tips two :Search "iCSee" in the App store or Googleplay and download.

2.Power on

Install the memory card first, then install the battery and turn on the device (Memory card does not support hot plug - in. please plug - in memory card when the device is power - off).

3.Camera configuration

01.User login

- Open "iCSee", sign up a new account and log in(Figure1);
- If you have Wechat .You can use" WeChat shortcut login" directly (Figure1);



02.Internet connection

 Click "+" in the upper right corner to enter the device configuration page, and click "Add My Device". (Figure 2)

(Figure 1)

Press and hold the Reset button on the device for 6 seconds to reset the device to the factory default settings and press the Reset button 1 time enters network configuration mode.

• Enter the router account and password according to the prompt of the APP and start configuring. (Figure 3)

Figure 3





03.Access device

Add Shared Device

Add device in the same WLAN

After logging success, you can use the mobile phone access the device through the APP, The device has the following states:



Device low battery or network failure:

Offline

APP notification message.

Set up in the device use



04.Message push

Awaking the time may be longer.

In this state, the device does not support the

remote wake-up function (or the device is set

up to prohibit remote wake-up). If the mobile

phone wants to view the device, it can be

wake-up remotely by mobile phone.

forced to wake up by manually pressing the

The device is in a low-power mode and can be

This state indicates that the device is waking

up from the rest state to the online state. It will take about 3 seconds. If the network is not good.

In this state, The mobile phone can make

various accesses to the device:

When PIR sensor detect someone moving, the device will send a message to your phone, you can receive the message in the following two ways:

1.Receive the message via the APP

dormancy device button.



2. Receive the message via WeChat.



Search in WeChat and use Wechat notification flow the "ICSEE" official

Notes: If the Mobile phone is set up to power saving mode, such as

screen off & network off, it will not receive the message in time, Since android phones do not agree on the default handling of message interceptions, it is recommended to use WeChat receive message except the iPhone and Huawei phones.

Q: How to store a video camera?

FAQ

A: Currently, the camera supports FAT32G format Class6, Class 10 TF Card, max supports 128G. When the TF Card is full, it will delete earlier video automatically and loop

Q:How to restore the factory default? A:When using in the new network environment, please long press the reset button (SET) for 6 seconds release the button. It means that restored to factory setting successfully. Then you can start to connect network configurati



While using this product, please modify the user password, to avoid the delinquents misappropriation.

Do not install the equipment in damp, dusty, children easy access to the venue.

App and device firmware will have new update irregularly, you could upgrade it online at app setting, instructions are for reference only.

Warranty period:one year. This warranty card is only for our company's products

Warranty Card Product

Model Name Purchase Purchase Date Store Cause

Please allow within the scope of use and storage of

temperature and humidity, do not disassemble it at will,

⚠ Directions

Process Customer Custome Gender Name Customer Phone ZIP Address