Daily Care

- The toothbrush slot is removable and washable, and easy to disassemble and install.
- Do not wash the whole device with water for its precision circuit and lithium battery.

Notices

- Pasted wall should be dry, dust-free and smooth, such as tiles, marble, glass and so on.
- Do not hang overweight items, please use this product in its bearing range.
- Attention should be paid to the battery waterproof, avoidance of violent impact, recycling and environmental protection.


Product Specification

Product Name: Smart Toothbrush Sanitizer	Product Model Number: C6	
Sterilization Way: UVA	Rated Power: 1.5W	
Charging Input: 1000mA	Battery Capacity: 4800mAh	
Charging Time: 5 hours	Sterilization Wavelength: 200~280nm	
Installation Way: Bonded	Package Size: 194*120*60mm	



Smart Toothbrush Sanitizer Operation Instruction

Service mail: yuany526@gmail.com







Let the wall be dry. dust-free and smooth

Viscose



Paste to the wall

and let stand for install successfull 24 hours

Product Function

1.UVA Sterilization

This product uses Philips DUV chip to sterilize, UVA to inhibit bacteria. The sterilization rate is as high as 99,99%.

UVA Sterilization Opening Methods:

- a. Press the power button to start. Sterilization will stop automatically after 2 minutes
- b. The sterilizer sterilizes automatically eight times a day, one minute each time

Automatic sterilization time as follows:

AM	5:00	7:00	9:00	11:00
PM	17:00	19:00	21:00	23:00

^{*}To avoid UVA radiation, sterilization is done only when no one is near.

2.Time adjustment

You need to set the machine time when you get it at first time.

Set hours: Long press the top button "H", the screen displays "08:-" to enter the hour setting mode. Then, press "H/M" to add or subtract. Long press the top button "H" again to confirm the completion of the setting. Set minutes: Long press the top button "M", the screen displays "--:08" to enter the minute setting mode. Then, press "H/M" to add or subtract. Long press the top button "M" again to confirm the completion of the

Battery Indicator

setting.

This product has the reminder function of power shortage, charging process and charging completion.

- 1. The charging icon on the screen flashes when someone is near the device whose power is below 20%.
- 2. The charging icon on the screen lights up when the device is charging.
- 3. The charging completion icon lights up after the charging is completed.

The device is equipped with a Type-C data cable, which can be charged with a phone charger plug or a charger bank. It can be fully charged after about 4 to 6 hours